





**Technical Information**  
Explosion Drawings and Parts List

**TABLE WITH WHEELS MT58K (Version MT58K B )**

Pos. Ref.	Description	Pos. Ref.	Description
1	2085002	HEX. NUT M.6	
2	1580017	WASHER D.6.2X21X2	
3	5821236	BUSHING	
4	4375066	HEX. SOCKET HD. CAP SCREW M.6X35	
5	5821255	BUSHING	
6	5875100	SCREW M.6X50	
7	5821247	BUSHING	
8	1675045	HEX. SOCKET HD. CAP SCREW M.6X15	
9	5833124	ROD	
10	5845313	ROD ASS'Y	
11	5888107	PIN D.4X28	
12	5899150	WHEEL D.200	
13	5880042	WASHER D.21	
14	1699139	COVER	
15	5821245	BUSHING	
16	5806253	BRACKET	
17	5806252	SUPPORT	
18	4380012	WASHER D.6.4 DIN125	
19	5875101	SCREW M.6X45	
20	5806255	BRACKET	
21	5806254	SUPPORT	
22	1675037	HEX. SOCKET HD. CAP SCREW M.6X12	
23	5899152	COVER 30X15	
24	5845312	LEGS ASS'Y	
25	5899154	SUPPORT	
26	5845321	HANDCAR ASS'Y	
27	5899151	COVER D.22	
28	5845353	LEGS ASS'Y	
29	5845324	PROTECTOR ASS'Y	
30	5821249	HANDLE	
31	5804205	PROTECTOR	
32	5889050	WING NUT M.8	
33	4371028	HEX. HEAD SCREW M.8X65	
34	1180003	WASHER D.8.4 DIN125	
35	5823259	PROTECTOR BRACKET	
36	4919231	LABEL	
37	1689011	RIVET D.4X8	
38	5080007	WASHER D.10.5 DIN125	
39	5821237	BUSHING	
40	5819234	LABEL	
41	5819233	LABEL	
42	5823253	TABLE	
43	5845354	ROD ASS'Y	
44	5884013	WASHER D.6.2X21X1	